

Displaying the Energy Rating Label

This guide supports the correct display of Energy Rating Labels when supplying, or offering to supply, the following products in Australian retail stores.

Clothes dryers




- ▶ Upper front of the product facing the consumer or packaging preferred. Lower front is also OK.
- ▶ May be fixed to top but ensure not to obscure it

Clothes Washers



Refrigerators



- ▶ Front of product or packaging facing the consumer at the top of any display panel on the refrigerator.

Freezers



- ▶ Front of product or packaging.
- ▶ May be fixed to top but ensure not to obscure it

Dishwashers



- ▶ Front of product or packaging facing the consumer at the top of any display panel on the dishwasher.
- ▶ If the product is outside its packaging and has more than one opening/draw an ERL must be on each opening.

Detailed information for each appliance is available at www.energyrating.gov.au/industry-information/products

Televisions



Computer monitors



- ▶ Front of product or packaging.
- ▶ The label must be attached in a way that discourages removal of the label in store.

Air Conditioners



- ▶ If there are units of the product on display in a retail store, you must make sure that at least one Energy Rating Label is clearly visible in relation to the display.
- ▶ Front of the product or packaging is ideal.

Swimming pool pumps



- ▶ At least one label clearly visible for the display:
 - ▶ If out of the box, the ERL must be adhered to the unit or printed on a double-sided swing tag or non-rotating single-sided swing tag.
 - ▶ if models are packaged — label must be adhered to, printed on or part of the outside of each package.